

9/2/10, 09:24

5 ELECTRICAL WIRING


HOW TO CONNECT WIRING TO THE TERMINALS

A. For solid core wiring


- Cut the wire end with a wire cutter or wire-cutting pliers, then strip the insulation to about 25 mm (1 5/16") of expose the solid wire.
- Using a screwdriver, remove the terminal screw(s) on the terminal board.
- Using pliers, bend the solid wire to form a loop suitable for the terminal screw.
- Shape the loop wire properly, place it on the terminal board and tighten securely with the terminal screw using a screwdriver.

B. For strand wiring

- Cut the wire end with a wire cutter or wire-cutting pliers, then strip the insulation to about 10 mm (3/8") of expose the strand wiring.
- Using a screwdriver, remove the terminal screw(s) on the terminal board.
- Using a round terminal fastener or pliers, securely clamp a round terminal to each stripped wire end.
- Position the round terminal wire, and replace and tighten the terminal screw using a screwdriver.



1. WIRING SYSTEM DIAGRAM



WARNING

Disconnect switch and circuit breaker for over current protection given in the table below is to be installed between the indoor unit and the outdoor unit.

Disconnect switch	Circuit breaker (or Fuse)
15A	240 V - 5A

CAUTION


- Be sure to refer the above diagram and do correct field wiring. Wrong wiring causes malfunction of the unit.
- Check local electrical codes and also any specific wiring instructions or limitation.

2. INDOOR UNIT SIDE


WARNING

- Before starting work, check that power is not being supplied to the indoor unit and outdoor unit.
- Match the terminal board numbers and connection cord colors with those of the outdoor unit. Erroneous wiring may cause burning of the electric parts.
- Connect the connection cord firmly to the terminal board. Imperfect installation may cause a fire.
- Always fasten the outside covering of the connection cord with the cord clamp. (If the insulator is chafed, electric leakage may occur.)
- Always connect the ground wire.

- Remove the control box cover and terminal box cover and install the connection cord and remote controller cord.




- After wiring is complete, clamp the remote controller cord and connection cord with the cord clamp.



Ceiling height setting

Set the DIP switch for the ceiling height according to the table below.

Ceiling height		DIP-SW4		
		1	2	3
2.5-3.0 m (8.2-9.8 ft)	Normal	—	OFF	OFF
3.0-3.5 m (9.8-11.5 ft)	High ceiling 1	—	ON	OFF
More than 3.5 m (More than 11.5 ft)	High ceiling 2	—	OFF	ON
Less than 2.5 m (Less than 8.2 ft)	Low ceiling	—	ON	ON




CAUTION

- If the setting for a low ceiling is selected, the capacity of the air conditioner decreases slightly.
- Do not set any switches other than those specified in this sheet. The air conditioner may not operate correctly if any switches other than those specified are changed.

6 GRILLE INSTALLATION


BLOWER COVER INSULATION

Install the blower cover insulation only when the outlet direction is not specified.
Two blower cover insulations are packed with the indoor unit. Install the blower cover insulation at the diffuser position shown in figure. At this time, use the piping position as the criteria.




INSTALLING THE INTAKE GRILLE


- Mount the grille hinge wire to the hook shaft as shown in figure.




- Latch the grille hinge wire to the hook shaft, and fasten.




- Install the hook wire.
 - Pass the hook wire through the panel base from the rear side as shown in figure, and fasten to the reinforced metal fitting of the intake grille using a screw.



Section view




- Loosen the screw, put the loop of the hook wire over it, and tighten the screw again.



CAUTION

Install the intake grille hook wire to the grille assembly. If it falls, it may cause injuries.



7 REMOTE CONTROLLER SETTING

CAUTION


- When detecting the room temperature using the remote controller, please set up the remote controller according to the following conditions.
 - If the remote controller is not well set, the correct room temperature will not be detected, and thus the abnormal conditions like "not cooled" or "not heated" will occur even if the air conditioner is running normally.
 - A location with an average temperature for the room being airconditioned.
 - Not directly exposed to the outlet air from the air-conditioner.
 - Out of direct sunlight.
 - Away from the influence of other heat sources.

- When installing the remote controller and cord near a source of electromagnetic waves, separate the remote controller from the source of the electromagnetic waves and use shielded cord.

- Do not touch the remote controller PC board and PC board parts directly with your hands.


1. INSTALLING THE REMOTE CONTROLLER

- Open the operation panel on the front of the remote controller, remove the two screws indicated in the following figure, and then remove the front case of the remote controller.



- When installing the remote controller, remove the connector from the front case. The wires may break if the connector is not removed and the front case hangs down.
When installing the front case, connect the connector to the front case.

- Install the rear case to the wall, etc. with the two tapping screws. Refer to the following information to install the remote controller wires.




- Install the remote controller wire so as not to be direct touched with your hand.

2. ROUTING THE REMOTE CONTROLLER WIRES


- Install the remote controller wires to the terminals on the top of the rear case as shown in the following figure.
- Fasten the wires with the binder.

(Example)



3. SETTING THE DIP SWITCHES

When using a battery (memory backup)




Change the DIP switch setting to use batteries. (The DIP switch is not set to use batteries at the factory.)
Change DIP switch 1 No. 6 from OFF to ON.
If batteries are not used, all of the settings stored in memory will be deleted if there is a power failure.

4. SETTING THE ROOM TEMPERATURE DETECTION LOCATION

The detection location of the room temperature can be selected from the following three examples. Choose the detection location that is best for the installation location.

A. Indoor unit setting (factory setting)

The room temperature is detected by the indoor unit temperature sensor.




When the THERMO SENSOR button is pressed, the lock display flashes because the function is locked at the factory.



B. Remote controller setting


The room temperature is detected by the remote controller temperature sensor.




- Press the THERMO SENSOR button for 5 seconds or more to unlock the function. The thermo sensor display flashes and then disappears when the function is unlocked.
- Press the THERMO SENSOR button. The thermo sensor display appears.
- Press the THERMO SENSOR button again for 5 seconds or more to lock the function. The thermo sensor display flashes and then remains on when the function is locked.
- Make sure that the function is locked.

C. Indoor unit/remote controller setting (room temperature sensor selection)

The temperature sensor of the indoor unit or the remote controller can be used to detect the room temperature.



- Press the THERMO SENSOR button for 5 seconds or more to unlock the function. The thermo sensor display flashes and then disappears when the function is unlocked.
- Press the THERMO SENSOR button to select the temperature sensor of the indoor unit or the remote controller.



CAUTION

- When select the "Remote controller setting", if the detected temperature value between the temperature sensor of the indoor unit and the temperature sensor of the remote controller varies significantly, it is likely to return to the control status of temperature sensor of the indoor unit temporarily.

- As the temperature sensor of remote controller detects the temperature near the wall, when there is a certain difference between the room temperature and the wall temperature, the sensor will not detect the room temperature correctly sometimes. Especially when the outer side of the wall on which the sensor is positioned is exposed to the open air, it is recommended to use the temperature sensor of the indoor unit to detect the room temperature when the indoor and outdoor temperature difference is significant.


- The temperature sensor of the remote controller is not only used when there is a problem in the detection of the temperature sensor of the indoor unit.

NOTES

If the function to change the temperature sensor is used as shown in examples A and B (other than example C), be sure to lock the detection location. If the function is locked, the lock display will flash when the THERMO SENSOR button is pressed.

8 TEST RUN

- Stop the air conditioner operation.
- Press the MODE button and the FAN button simultaneously for 2 seconds or more to start the test run.




- Press the START/STOP button to stop the test run.

[SELF-DIAGNOSIS]

When the error indication "E.EE" is displayed, follow the following items to perform the self-diagnosis. "E.EE" indicates an error has occurred.

1. REMOTE CONTROLLER DISPLAY

- Stop the air conditioner operation.
- Press the SET TEMP. buttons Δ / ∇ simultaneously for 5 seconds or more to start the self-diagnosis. Refer to the following tables for the description of each error code.




- Press the SET TEMP. buttons Δ / ∇ simultaneously for 5 seconds or more to stop the self-diagnosis.

Error code	Error contents
00	Communication error (indoor unit — remote controller)
01	Communication error (indoor unit — outdoor unit)
02	Room temperature sensor open
03	Room temperature sensor short-circuited
04	Indoor heat exchanger temperature sensor open
05	Indoor heat exchanger temperature sensor short-circuited
06	Outdoor heat exchanger temperature sensor
08	Power source connection error
09	Floater switch operated
0A	Outdoor temperature sensor
0C	Discharge pipe temperature sensor
11	Model error
12	Indoor fan error

Error code	Error contents
13	Outdoor signal error
14	Excessive outdoor pressure (permanent stop)
15	Compressor temperature sensor
16	Pressure switch error
17	IPM error
18	CT error
19	Active filter module (AFM) error
1A	Compressor does not operate
1b	Outdoor unit fan error
1C	Communication error (inverter — multicontroller)
1d	2 way valve sensor error
1E	Expansion valve error
1F	Connection indoor unit error

2. CHECKING DRAINAGE

To check the drain, remove the water cover and fill with 2 to 3 l of water as shown in figure. The drain pump operates when operating in the cooling mode.




9 SPECIAL INSTALLATION METHODS

CAUTION

- When setting the rotary switch and DIP switches, do not touch any other parts on the circuit board directly with your bare hands.
- Be sure to turn off the main power.


1. GROUP CONTROL SYSTEM

A number of indoor units can be operated at the same time using a single remote controller.



- Rotary switch setting (indoor unit)
Set the unit number of each indoor unit using the rotary switch on the indoor unit circuit board. The rotary switch is normally set to 0.


- DIP switch setting (remote controller)
Change DIP switch 1 No. 3 on the remote controller from OFF to ON.



2. DUAL REMOTE CONTROLLERS (OPTIONAL)

Two separate remote controllers can be used to operate the indoor units.

- Wiring method (indoor unit to remote controller)



- DIP switch setting (remote controller)
Set the remote controller DIP switch 1 No. 1 and 2 according to the following table.

Number of remote controllers	Master unit		Remote controller
	DIP-SW 1 No. 1	DIP-SW 1 No. 2	
1 (Normal)	ON	OFF	DIP Switch 1
2 (Dual)	OFF	OFF	


Number of remote controllers	Slave unit	
	DIP-SW 1 No. 1	DIP-SW 1 No. 2
1 (Normal)	—	—
2 (Dual)	ON	ON

3. AUTO RESTART

- When the air conditioner power was temporarily turned off by a power failure etc., it restarts automatically after the power recovers. (Operated by setting before the power failure)

The auto restart function can be canceled.

- DIP switch setting (indoor unit)
Change the DIP switch (SW1-1) on the indoor unit circuit board from ON to OFF. The auto restart function will be canceled.



[DIP-SWITCH SETTING]

● Indoor unit


DIP-Switch	NO.	SW state		Detail
		OFF	ON	
DIP-Switch 1	1	Invalidity	Validity *	Auto restart setting
	2	—	—	Temperature correction setting
	3	—	—	Remote controller setting
DIP-Switch 4	1	—	*	Remote controller setting
	2	—	*	Air flow setting

● Remote controller

	No.	SW state		Detail
		OFF	ON	
DIP-switch 1	1		*	Dual remote controller setting
	2	*		Group control setting
	3	* One unit	Multiple units	Model setting
	4	* Heat & cool mode	Cooling only mode	AUTO changeover setting
	5	Invalidity	* Validity	Memory Backup setting
DIP-switch 2	6	* Invalidity	Validity	THERMO SENSOR button setting
	1	* Validity	Invalidity	ENERGY SAVE button setting
	2	* Validity	Invalidity	Horizontal airflow direction and swing button setting
	3	Validity	* Invalidity	Vertical airflow direction and swing button setting
	4	* Validity	Invalidity	Cannot be used.
	5	* Fixed at OFF	Invalidity	Cannot be used.

(*: Factory setting)

10 OPENING THE DUCT CONNECTION HOLE




CAUTION

- When performing hole opening work, be careful not to damage the drain pan.
- When connecting the distribution duct, to make the air flow easily, block the outlet port with the blower cover insulation as shown by the hatched lines in the figure. For the blocking direction, refer to blower cover insulation figure.


1. DIMENSION

Screw position and connection hole which are fresh air duct and distribution duct.




2. DISTRIBUTION DUCT AND FRESH AIR DUCT HOLE PROCESSING

Use the distribution duct hole and fresh air duct hole by removing the insulation material as shown below.



- Cut off the part (Cabinet) indicated by the arrow in the figure with nippers, needle nose pliers, etc.



- Open the holes and cut the insulation with a knife.
 - * Be careful not to damage the internal parts.
 - * Be careful not to cut yourself on the cutout in the metal plate.
 - * Please remove the insulation (inner box) left over after cutting.
- Connect the distribution duct.
 - * When mounting the duct, block the gap so that there is no cold air leakage.
 - * Insulate the duct and cut connection.

CAUTION

The air conditioner cannot take in fresh air by itself. When connecting a fresh air duct, always use a duct fan.