

INSTALLATION INSTRUCTIONS

BUILT-IN THERMOSTAT

CAUTION: Disconnect supply service to avoid electric shock. All wiring connections must conform to national electric code and local codes having jurisdiction.

NOTES:

- * Do not eliminate or bypass the thermal cutout.
 - * Be sure load controlled by the thermostat does not exceed the thermostat nameplate rating.
 - * The in-built thermostat accessory can be mounted in either end of baseboard.
1. Remove junction box cover.
 2. Remove wire nut in junction box (Do not disturb the crimp connection).
 3. Install thermostat accessory in the junction box with the two (2) screws provided.
 4. Make connections per wiring diagram. Connect read lead wire(s) to line supply and black lead wire(s) to load.
 5. Install one of the new junction box covers provided. Reinstall cover so the thermostat shaft extends through cover. Press control knob.
 6. Restore power to the baseboard.
 7. Thermostat operation: Turn thermostat shaft fully clockwise. When the room has reached the desired comfort level, slowly turn thermostat shaft counter-clockwise until heater turns off (a faint click will be heard). One or two minor adjustments may be required.

TAMPER RESISTANT THERMOSTAT INSTALLATION

1. Repeat steps 1, 2, 3, 4, 5, 6 and 7.
2. Reinstall junction box cover (Do not remove knockout).

