

MASON INDUSTRIES, Inc.

Manufacturers of Vibration Control Products

Hauppauge, NY 11788 631/348-0282 FAX 631/348-0279 Info@Mason-Ind.com

350 Rabro Drive 2101 W. Crescent Ave., Suite D Anaheim, CA 92801 714/535-2727 FAX 714/535-5738 Info@MasonAnaheim.com

HD **NEOPRENE HANGER** INSTALLATION INSTRUCTIONS

DATE: 6-21-2001 DRAWING NO.

- 1. INSTALL EQUIPMENT IN ITS OPERATING POSITION, TEMPORARILY SUPPORTED WITH RIGGING AS REQUIRED.
- 2. ATTACH HANGER BOXES TO UPPER AND LOWER RODS.
- 3. ADJUSTMENT IS MADE BY TURNING TOP NUTS ON THE LOWER RODS THAT PASS THROUGH THE NEOPRENE ELEMENT. TAKE 3 CLOCKWISE TURNS ON EACH HANGER NUT TO COMPRESS THE ELEMENT UNIFORMLY AND AVOIDING OVERLOADING INDIVIDUAL HANGERS. THE SAME ADJUSTMENT CAN BE MADE BY TURNING THE NUTS ON THE BOTTOM OF THE HANGER RODS IF MORE CONVENIENT. IT IS VERY IMPORTANT THAT THE HANGERS ARE ADJUSTED UNIFORMLY. REPEAT THIS PROCEDURE UNTIL THE RIGGING CAN BE REMOVED.
- LEVEL EQUIPMENT BY TAKING ADDITIONAL TURNS AT THE LOW CORNER 4. OR SIDE.

DWN: JT CHKD: DATE: 6-21-2001