


Kit Components (cont'd)



NOTE: The concentric adapter box comes in a variety of sizes and may not look exactly like the photo.

Field-supplied See **specific** requirements in the heater installation manual. Requirements vary by model and size.

Components . Vert Pipe

- Combustion air pipe
- Flashing
- Taper-type connections to reduce or enlarge the pipe run
- Thimble (A thimble is not required if roof or wall is of non-combustible construction unless required by local code.)
- Mounting brackets for concentric adapter box (or box may be flush with the wall, depending on building construction)
- Sheetmetal screws and sealant for joints as needed for pipe being used

Tools/Supplies Required for Installation

Screwdriver or drill for securing box, pipes, caps, and guard; tools and hardware for installing wall or roof flashing; tools for installing thimble if required; duct tape; high temperature sealant; lubricant for rubber seal (Installation Tip: Spray cooking oil works well to lubricate the rubber seal.)

Follow the instructions in the heater or venting installation manual.

(800)695-1901

www.ReznorOnline.com

Thomas & Betts

Form I-OPT-VC, Page2

©2002 Thomas & Betts Corporation, All rights reserved. Printed in the U.S.A.
 MANUFACTURER OF HEATING, COOLING, AND VENTILATING SYSTEMS
 Trademark Note: Reznor® and TCORE²® are registered in at least the United States.
 YL POD 8/02 Form RZ-NA I-OPT-VC (Version A)