


AC Heat Pump with Standard Air Handler and Two Stage Electric Backup Heat

- R ● 24 Volt+
- G ● Fan Only Operation
- C ● Common
- Y ● Air Conditioning–Heat Pump
- O ● Reversing Valve
- W² ● Backup Electric Heat
- E ● Second Stage Emergency Heat



Wire Size: 18 Gauge

NOTE: Some AC systems will have a blue wire with a pink stripe in place of the yellow or Y wire.

This diagram is to be used as a reference for the low voltage control wiring of your heating and AC system. Always refer to your thermostat or equipment installation guides to verify proper wiring.