

## Honeywell Y8835 Zone Control Capabilities.

**Honeywell Y8835A1028 EnviraZone Kit** 3-zone w/3 VisionPro IAQ thermostats

**Honeywell Y8835A1044 EnviraZone Kit** 2-zone w/2 VisionPro IAQ thermostats

These two kits allow full programmability (time/temperature events) for each of the zones controlled by each VisionPro IAQ thermostat. Upon connection of the thermostats to the main control panel, the main control panel will communicate with the thermostats. The installer/homeowner must follow the individual thermostat's installation instructions to:

**A)** Identify it as a Zone 1, 2, or 3 thermostat.

**B)** Program the zone's time/temperature settings as you would any individual thermostat.

The Zone 1 thermostat is the controller for the settings on the main control panel, per the manufacturer's instructions. You **cannot** control thermostats in other zones from the Zone 1 thermostat.

Once the thermostats are programmed, the main control panel will operate the heating/cooling system and open/close the specific dampers accordingly, based upon default cycling settings from the manufacturer. The systems are expandable up to nine zones with the purchase of an additional VisionPro IAQ thermostat for each expanded zone.

**Honeywell Y8835A1051 EnviraZone Kit** 3-zone w/1 VisionPro IAQ and 2 FocusPro 5000 thermostats

**Honeywell Y8835A1036 EnviraZone Kit** 2-zone w/1 VisionPro IAQ and 1 FocusPro 5000 thermostat

These two kits allow programmability (time/temperature events) only in the zone controlled by the VisionPro IAQ thermostat. The FocusPro 5000 thermostats are non-programmable, thus zones controlled by the FocusPro 5000 thermostats have no programming capability. Upon connection of the thermostats to the main control panel, the main control panel will communicate with the thermostats. The installer/homeowner must follow the thermostat's installation instructions to:

**A)** Identify it as Zone 1, 2, or 3 thermostat.

**B)** Program the time/temp settings for the zone controlled by the VisionPro IAQ thermostat.

**C)** Set desired temperature for the FocusPro 5000 thermostat(s) as you would any individual thermostat.

The Zone 1 thermostat is the controller for the settings on the main control panel, per the manufacturer's instructions. You **cannot** control thermostats in other zones from the Zone 1 thermostat.

Once the VisionPro IAQ thermostat is programmed, the main control panel will operate the heating/cooling system and open/close the specific dampers accordingly, based upon default cycling settings from the manufacturer. The systems are expandable up to nine zones with the purchase of an additional FocusPro 5000 thermostat for each expanded zone.