



1. Unscrew feeder tube completely from the evaporator coil.




2. Here is the feeder tube that has been removed from the evaporator coil.




3. Cut the zip tie from the liquid suction lines.



4. Remove the cap from the suction line.







5. Release the pressure in the coil by pressing the Schrader valve down until all nitrogen has been released from the unit.

6. Unscrew hex nut completely from the liquid line on the evaporator coil.




7. Here
is the
hex nut
removed.
Note:
Leave in
white
O-Ring.





8. Slide feeder tube through back end of hex nut so the flared side will be facing out.



9. Re-attach hex nut, with feeder tube pulled through the nut, to the coil. Flared end facing away.

10. Tighten hex nut with a wrench to finish.

